Key safe

SSZ 300





Extra-large design

With adjustable 4-digit number code

Access for different people



MOUNTING/OPERATING INSTRUCTIONS







General notes

Intended use

In a key safe, you can safely store all your keys and use a numeric code to grant access to more than one person. In so doing, a key hand-over may be organised in a secure and quite flexible fashion.

Please follow the instructions given in this manual in order to mount and operate the key safe correctly.

warnings: No hazards are to be expected, if the device is used correctly and in accordance with the instructions. Small parts and packaging materials can be swallowed by children and lead to choking! Make sure that small parts and packaging materials are kept out of reach of children. Dispose of the packaging material immediately.

The key safe comes with a weather-proof housing made of aluminium. The combination lock with adjustable 4-digit number combination is protected by a flap featuring a sliding mechanism. The key safe is finished with rust protection and is also suitable for wall mounting. The corresponding mounting material is supplied with the safe.

The manufacturer expressly reserves the right to make technical changes.

Disclaimer

The manufacturer accepts no liability for damage or injury resulting from incorrect handling.

Cleaning/maintenance

You can easily wipe off any minor soiling of the key safe with a damp cloth.

Disposal



Help to protect the environment and dispose of the product and the packaging

materials in accordance with the local regulations.

Scope of delivery

Check that the delivery is complete:

- 1x key safe
- 1x operating manual
- 1x mounting material

© Copyright

Reproduction or duplication (even excerpts thereof) is forbidden without approval of: BASI GmbH Konstantinstraße 387 41238 Mönchengladbach, Germany

2023


This publication, including all its parts, is protected by copyright.


Any use outside the narrow limits of copyright law without the consent of BASI GmbH is not allowed and is liable to prosecution.


This applies in particular to duplications, translations, microfilming and importing and processing in electronic systems.

BASI GmbH, Konstantinstraße 387, 41238 Mönchengladbach, Germany

SSZ 300 key safe









4) RESET switch

- 1) Lock
- 2) Open
- 3) Combination lock


Changing the numerical password

- 1. Set the RESET switch to position B.
- 2. Set your desired 4-digit number combination.
- Set the RESET switch back to position A.
 Your new number combination is now in effect. Be sure to memorise it.
- 4. Shut the front flap of the key safe.

Mounting the key safe

The key safe is designed for both indoor and outdoor usage.

- 1. Open the key safe by setting the digits to the starting position 0-0-0-0 and pressing the opener. Now pull the front flap of the key safe towards you.
- Mark the drill holes at the desired drilling location.
 Please use the back of the key safe as a template.



Drill the holes.



Caution: Make sure that no cables or pipes are routed along the selected drilling point. Doing so can pose a risk of injury or damage to the surrounding area!

Place the dowels in the drilled holes.



Note: Be aware that the supplied fastening material could prove incompatible with the desired mounting location. You can purchase fastening materials that correspond to the location in question from your local hardware store.

5. Hold the key safe against the drill holes and fasten the screws into the dowels with the help of a screwdriver. Then fasten the key safe in place with the screws.

